

# Table of Contents

<b><u>B-Frame Parity Errors</u></b> .....	<b>1</b>
<u>Document ID: 10804</u> .....	1
<u>Introduction</u> .....	1
<u>Prerequisites</u> .....	1
<u>Requirements</u> .....	1
<u>Components Used</u> .....	1
<u>Conventions</u> .....	1
<u>What are they?</u> .....	1
<u>What do they mean?</u> .....	1
<u>What should I do to make them go away?</u> .....	2
<u>NetPro Discussion Forums – Featured Conversations</u> .....	2
<u>Related Information</u> .....	2

# B-Frame Parity Errors

Document ID: 10804

---

**Introduction**

**Prerequisites**

Requirements

Components Used

Conventions

**What are they?**

**What do they mean?**

**What should I do to make them go away?**

**NetPro Discussion Forums – Featured Conversations**

**Related Information**

---

## Introduction

This document defines B-Frame Parity errors and explains how to get rid of them.

## Prerequisites

### Requirements

There are no specific requirements for this document.

### Components Used

This document is not restricted to specific software and hardware versions.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

### Conventions

For more information on document conventions, refer to the Cisco Technical Tips Conventions.

## What are they?

B-Frame Parity errors indicate an error in the header portion of the frame. Errors in this portion of the frame mean that the routing information in the frame has been corrupted, so the frame may not go to the correct destination. For this reason, the frames are discarded.

## What do they mean?

The exact interpretation of B-Frame Parity errors varies slightly between the cards that use the Xilinx-based BIF-RX and the Monarch cards that use the SIMBA ASIC.

For the BIF–RX based cards, this error means that the first word had an error in the horizontal parity. For the SIMBA, this error means either one of the first four words had an error in the horizontal parity, or that the intermediate, vertical parity BIP–16, that covers the first seven words, had an error.

## What should I do to make them go away?

They are errors on the point–to–point data path, so they fit into the general category of debug. These errors are generally seen with BIP–16 errors and can be anywhere from the BCC cross–point, backplane to the line or trunk cards. Isolation is the difficult part with these errors, due to a long path through multiple cards which is mostly entirely unique to a particular slot to slot transmission. One needs to use all information available to minimize the number of pieces of hardware that are suspect.

If multiple cards report the errors, there is a good chance that a transmit path problem exists. One clue to the source might be a particular card or port which does not show any errors, since it is less likely to send to itself.

## NetPro Discussion Forums – Featured Conversations

Networking Professionals Connection is a forum for networking professionals to share questions, suggestions, and information about networking solutions, products, and technologies. The featured links are some of the most recent conversations available in this technology.

NetPro Discussion Forums – Featured Conversations for WAN Switching
---

Network Infrastructure: WAN Routing and Switching
---

---

## Related Information

- [Cisco WAN Switching Solutions – Cisco Documentation](#)
  - [Guide to New Names and Colors for WAN Switching Products](#)
  - [Downloads – WAN Switching Software](#)
  - [Technical Support – Cisco Systems](#)
- 

All contents are Copyright © 1992–2004 Cisco Systems, Inc. All rights reserved. Important Notices and Privacy Statement.

---

Updated: Dec 07, 2004

Document ID: 10804

---